

本手冊涵蓋的產品



CSEG20




CSEG25

推薦鞋帶

φ2.0 mm 非彈性繩	CSEG20
φ2.5 mm 非彈性繩	CSEG25

組 裝 方 法

■ Part & Detail ■



■ STEP 1 ■



將繩子末端從箭頭指示方向穿入 Base-part 的 Cord-slot。

■ STEP 2 ■




將另一條繩子以相同方式穿入，並按產品規格的指定長度打結。

■ STEP 3 ■



剪掉任何額外長度。
(使用刀具時請注意避免受傷)

■ STEP 4 ■




用打火機等燒熔切口，以防止因鬆散導致結鬆脫 (注意燙傷)。

■ STEP 5 ■



拉緊繩子，將結嵌入 Knot-Slot。

■ STEP COMPLETED ■



按照箭頭指示插入 CAP-part，并确保 Cap-part 的 Locking-tabs 与 Base-part 的孔对接，完成。

■ NOTE ■



若使用的繩子過粗，結會過大，可能導致 CAP-part 組裝困難。此時建議使用 Sheet Bend，結法請參考編號 AM000。

本手冊涵蓋的產品



CSEG (No,AM018)



CSD4 (No,AM017)

推薦鞋帶

φ2.0 mm 非彈性繩

φ2.5 mm 非彈性繩

HOW TO MAKE A "Sheet-bend"

Sheet bend

(Weaver's knot, weaver's hitch) 接繩結

■ STEP 1 ■

Make a loop with the Left-cord and pass the Right-cord through the loop from underneath.

用左繩打個圈，將右繩從下方穿過該圈。

■ STEP 2 ■

Thread the Right-cord behind the loop made by the Left-cord.

將右繩子從左繩子形成的環後方穿過。

■ STEP 3 ■

Pass the right cord through the space between the right cord from **STEP 1** and the loop of the left cord.

將右繩穿過**STEP 1**的右繩與左繩圈之間。

■ STEP 4 ■

Pull the base ends of both cords outward to tighten.





將左右兩條繩子的根部向兩側拉緊。

■ STEP COMPLETED ■

Cut off any extra length, and it's done.
剪掉任何額外長度，即完成。

Left-cord 左繩

Right-cord 右繩



■ NOTE ■

This document explains one method of tying two cords together and is not an assembly manual for our products. The difficulty of the knot coming undone may vary depending on the material, thickness, and stiffness of the cords used. It is necessary to test with the actual cords you intend to use.

本文件僅說明一種將兩條繩子連接的結繩方法，並非本公司產品的組裝說明書。結繩的牢固程度會因所使用繩子的材質、粗細及硬度而有所不同。請務必使用實際要使用的繩子進行測試。